

Shadow Newel Cap

WONCS1/90

FITTING INSTRUCTIONS

This template is created on a 1:1 scale to fit our 90mm posts. Cut the template to fit on top of your 90mm newel post, the round holes should align with 35mm centres from the corners of the post.

Once the holes are marked out you will need to drill 10mm holes to a depth of 40mm into the top of the post making sure these are perpendicular.

Dry fit the dowels into the cap and post making sure the cap lines up with the edges of the post. Once aligned remove dowels and apply a bead of glue into the cap holes and to the end of the dowels and re-insert into the cap.

Apply a bead of glue around on the top of the post, taking care not to be too generous so that it will drip over the edges once fixed in place, apply a bead of glue into the holes in the top of the post and fit cap, placing a weighted object on the cap whilst the glue dries will help with adhesion

